

National Guard Products Inc.

1-800-
647-7874



Door Sweeps

Installation Instructions

1. Cut sweep to fit.
2. Close door. Hold sweep at bottom of door. Tap down until contact is made between the sweep and threshold.
3. Mark screw holes.
4. Drill pilot holes for screws using a 7/64" drill bit.
5. Install with screws provided.
6. Adjust position so sweep does not impede proper closing and latching of door.



POSITIVE PRESSURE
TESTED GASKETING
MATERIALS FOR FIRE
DOORS. INTENDED
FOR APPLICATION TO
STEEL TYPE FIRE DOORS,
RATED UP TO 3 HOURS AND
WOOD TYPE FIRE DOORS,
RATED UP TO 1 1/2 HOURS.



GASKETING
MATERIALS FOR FIRE
DOORS

Smoke and Draft Control
gasketing (Category H) tested to UL
1784; meets requirements of NFPA
105, IBC for use on "S" label doors.